
NIRA 2

Spare parts · Exploded view





List of parts

1 **Body** P201
2 **Plunger rod** P202
3 **Plunger spring** R5657
4 **Plunger seal** (-89 and before) R56
5 **Plunger seal** (After year 1989) R606
6 **Plunger body** P61803
7 **Cylinder pipe** R608
8 **Cylinder seal** R604
9 **Shaft** P208
10 **Shaft O-ring seal** R2781224
11 **Handle** P210
12 **Handle ball grip** R211
13 **Bolt M8x110** R2008110
14 **Nut M8** R2268
15 **Bottom valve body** P214
16 **Bottom valve** R215
17 **Suction pipe** R217
18 **Nitrile seal set** R21 (-89 and before R2)
19 **Viton seal set** R2V1 (-89 and before R2V)
20 **Connection pipe** R19819
21 **Hose clamp** R2621928