
NIRA 3B

Spare parts · Exploded view



List of parts

1 **Cylinder valve body 1 1/4"** P29
2 **Cylinder pipe / plastic** P28
3 **Cylinder coupling 47,8x1/8"** P27
4 **Cylinder valve** R30
5 **Plunger seal** R56
6 **Cylinder plunger rod** P35
7 **Cylinder complete / plastic** P31
8 **Plunger complete** P605
9 **Riser pipe 1 mtr** M2100K
10 **Plunger rod 1 mtr** L2102
11 **Coupling 47,8x1/8** SD106
12 **Pump head pipe coupling** P34
13 **Base flange** SD1804
14 **Pump head pipe 1 1/2"** P33
15 **Pump head top** P31501
16 **Handle forked mounting (Blue)** P31502S
17 **Handle (Blue)** P31503S
18 **Pump Head Rod** P32
19 **Hexagonal screw M 8x50** R200850
20 **Nut M8** R2268
21 **Hexagonal screw M 12x80** R2001280
22 **Nut M12** R22612
23 **Hexagonal screw M10x40** R2001040
24 **Nut M10** R22610
25 **Bearing** R2821010

OPTIONAL pipe extension below the cylinder

26 **Suction pipe 40mm 1m** R2621140
27 **Coupling 1 ¼"x40mm** R26211440
28 **Non return valve 1 ¼"** 2002