NIRA 67

Spare parts · Exploded view



List of parts

1 **Cover Grey** R14766H
Cover Red R14766P
Cover Blue R14766S
2 **Rubber plug** R406
3 **Seal** R14832
4 **Screw** R206825
5 **Seal** R16787
6 **Screw** R20610201
7 **Mounting fork flange** P14705
8 **Bearing** P14750
9 **Shaft seal** RSL05
10 **Rocker arm** P14742
11 **Cotter pin** R242430
12 **Washer** SD404
13 **Handle fork mounting** P14744
14 **Clamping screw** R21256
15 **Handle** P14747
16 **Handle grip** R93B
17 **Pump head top** P14749
18 **Hosepipe adapter ¾”** R1570713
19 **Pump head pipe** SD302
20 **Base plate** SD1804
21 **Screw** R2288
22 **Nut** R202840
23 **Cylinder coupling** P27
24 **Cylinder plunger rod** P35
25 **Plunger complete** P605
26 **Plunger seal** R56
27 **Cylinder pipe** P28
28 **Cylinder valve** R30
29 **Cylinder valve body** P29
30 **Cylinder complete** P31
31 **Pump head rod** SD14373
32 **Riser pipe 1 m** M2100K
33 **Plunger rod 1 m** L2102
34 **Coupling** SD106

OPTIONAL pipe extension below the cylinder
35 **Coupling for suction pipe** R26211440
36 **Suction pipe** R1964058
37 **Bottom valve for suction pipe 1 ¼”** 2002