
NIRA 9

Spare parts · Exploded view



List of parts

1	**Body complete**	P901
2	**Shaft seal**	R903
3	**Cylinder Seal**	R410
4	**Plunger Seal**	R416
5	**Plunger complete**	P907
6	**Cylinder Pipe**	P908
7	**Bottom valve**	R909
8	**Bottom valve body with valves**	P910
9	**Gasket for flange**	R911
10	**Flange 1¼"**	P91806
11	**Flange 1½"**	P91807
12	**Nut M10**	R22610
13	**Nut M12**	R22612
14	**Handle rubber grip**	R919
15	**Seal collar**	P91802
16	**Nut M8**	R2268
17	**Nitrile seal set**	R9
18	**Bottom valve body without valves**	P91805
19	**Viton seal set**	R9V